

# Remote IO 4 AC Relay Moudule

□GFAR-RM02  
□GFAR-RM02S 簡易操作手冊 Quick Guide


## 包裝內容簡介 / Brief introduction

品名 / Product	數量 / Qty
4 AC relay module	1
簡易使用手冊	1

## 規格介紹 / Specifications


Technical Data	
Module type	4 AC relay module
Number of outputs	4
Power supply	5V DC via DINKLE Bus
Max. switching voltage	250 VAC / 30 VDC
Max. switching current	5A per channel
General Data	
W x D x H	12 x 100 x 95 mm
Operating temp.	0...+55°C
Storage temp.	-25...+85°C
Interface	Dinkle Bus system

## 外觀尺寸規格 / Dimensions




## 安裝拆卸說明 / Installation instructions

### 安裝 / Assembly



- 注意事項：安裝時請確認軌道與模組紅色箭頭是否同方向。
- Note: Both bus terminal and the module have red mark to indicate the direction while installation.

### 拆卸 / Back-out



## 建議搭配相關配件 / Related accessories

相關配件 / Accessories	料號 / Part No.
轉接插座	BS-210
轉接插頭	BS-211
標示牌	TM20
防塵蓋	BS-C028
USB / RS232	GFTL-RM01
USB / RS485	GFTL-RM02

Remote IO utility. Remote IO user manual.  
載點：[www.dinkle.com/en/news/download.php](http://www.dinkle.com/en/news/download.php)

