

Remote IO Master Module

GFMS-RM01N 簡易操作手冊 Quick Guide


包裝內容簡介 / Brief introduction

品名 / Product	數量 / Qty
master module	1
簡易使用手冊	1

規格介紹 / Specifications


Technical Data	
Module type	Modbus RS485
Max. expansion modules	247
Power supply	5V DC via DINKLE Bus
Current consump.	48mA @ 5V
Communication	
Interface	RS485
Interface connector	RJ45
Protocol	Modbus RTU/ASCII
Baud rate selectable	1200 to 1.5 Mbps
General Data	
W x D x H	20 x 100 x 95 mm
Weight	Approx. 80g
Operating temp.	0...+55°C
Storage temp.	-25...+85°C
Interface	Dinkle Bus system

外觀尺寸規格 / Dimensions




安裝拆卸說明 / Installation instructions

安裝 / Assembly



- 注意事項：安裝時請確認軌道與模組紅色箭頭是否同方向。
- Note: Both bus terminal and the module have red mark to indicate the direction while installation.

拆卸 / Back-out



建議搭配相關配件 / Related accessories

相關配件 / Accessories	料號 / Part No.
轉接插座	BS-210
轉接插頭	BS-211
標示牌	TM20
防塵蓋	BS-C028
USB / RS232	GFTL-RM01
USB / RS485	GFTL-RM02

Remote IO utility. Remote IO user manual.
載點：www.dinkle.com/en/news/download.php

